

# User's guide

# SMRA + MRA

Bearingless absolute encoder



Smart encoders & actuators

This publication was produced by Lika Electronic s.r.l. 2015. All rights reserved. Tutti i diritti riservati. Alle Rechte vorbehalten. Todos los derechos reservados. Tous droits réservés.

This document and information contained herein are the property of Lika Electronic s.r.l. and shall not be reproduced in whole or in part without prior written approval of Lika Electronic s.r.l. Translation, reproduction and total or partial modification (photostat copies, film and microfilm included and any other means) are forbidden without written authorisation of Lika Electronic s.r.l.

The information herein is subject to change without notice and should not be construed as a commitment by Lika Electronic s.r.l. Lika Electronic s.r.l. reserves the right to make all modifications at any moments and without forewarning.

This manual is periodically reviewed and revised. As required we suggest checking if a new or updated edition of this document is available at Lika Electronic s.r.l.'s website. Lika Electronic s.r.l. assumes no responsibility for any errors or omissions in this document. Critical evaluation of this manual by the user is welcomed. Your comments assist us in preparation of future documentation, in order to make it as clear and complete as possible. Please send an e-mail to the following address [info@lika.it](mailto:info@lika.it) for submitting your comments, suggestions and criticisms.



# General contents

User's guide.....	1
General contents.....	3
Subject Index.....	5
Typographic and iconographic conventions.....	6
Preliminary information.....	7
1 - Safety summary.....	8
Safety.....	8
Electrical safety.....	8
Mechanical safety.....	9
2 - Identification.....	10
3 - Mounting instructions.....	11
3.1 Overall dimensions.....	11
3.2 Magnetic ring.....	11
3.3 Installing the system.....	12
3.3.1 Mounting the magnetic ring.....	12
3.3.2 Mounting the sensor.....	12
3.3.3 Optional mounting tool.....	14
4 - Electrical connections.....	15
4.1 M8 cable specifications.....	15
4.2 M12 8-pin connector.....	15
4.3 Connection of the shield.....	16
4.4 Ground connection.....	16
4.5 Zero setting/Preset input.....	16
4.6 Counting direction input.....	16
5 - SSI interface.....	18
5.1 SSI (Synchronous Serial Interface).....	18
5.2 MSB left aligned protocol.....	19
5.3 Recommended transmission rates.....	20
5.4 Error bit.....	20
5.5 Helpful information.....	21
5.6 Recommended SSI circuit.....	21
6 - BiSS C-mode interface.....	22
6.1 Communication.....	22
6.2 Single Cycle Data SCD.....	23
6.2.1 SCD structure.....	23
Position.....	23
Error (nE).....	24
Warning (nW).....	24
CRC.....	25
6.3 Control Data CD.....	25
Register address.....	25
RW.....	25
DATA.....	26
CRC.....	26
6.4 Implemented registers.....	27
Preset.....	27
Preset setting enable.....	29
Serial number.....	29
Command.....	30

Save parameters.....	30
Save parameters and activate Preset.....	30
Device ID.....	30
Time-out.....	30
Software version.....	31
Manufacturer ID.....	31
6.5 Application notes.....	31
6.6 Recommended BiSS input circuit.....	32
7 - Diagnostic LED.....	33
8 - Error and fault diagnostics.....	34
9 - Maintenance.....	35
10 - Troubleshooting.....	36
11 - Default parameters list.....	37

# Subject Index

<b>C</b>	
Command.....	30
CRC.....	25 e seg.
<b>D</b>	
DATA.....	26
Device ID.....	30
<b>E</b>	
Error (nE).....	24
<b>M</b>	
Manufacturer ID.....	31
<b>P</b>	
Position.....	23
Preset.....	27




Preset setting enable.....	29
<b>R</b>	
Register address.....	25
RW.....	25
<b>S</b>	
Save parameters.....	30
Save parameters and activate Preset.....	30
Serial number.....	29
Software version.....	31
<b>T</b>	
Time-out.....	30
<b>W</b>	
Warning (nW).....	24

# Typographic and iconographic conventions

In this guide, to make it easier to understand and read the text the following typographic and iconographic conventions are used:

- parameters and objects both of Lika device and interface are coloured in **ORANGE**;
- alarms are coloured in **RED**;
- states are coloured in **FUCSIA**.

When scrolling through the text some icons can be found on the side of the page: they are expressly designed to highlight the parts of the text which are of great interest and significance for the user. Sometimes they are used to warn against dangers or potential sources of danger arising from the use of the device. You are advised to follow strictly the instructions given in this guide in order to guarantee the safety of the user and ensure the performance of the device. In this guide the following symbols are used:

	This icon, followed by the word <b>WARNING</b> , is meant to highlight the parts of the text where information of great significance for the user can be found: user must pay the greatest attention to them! Instructions must be followed strictly in order to guarantee the safety of the user and a correct use of the device. Failure to heed a warning or comply with instructions could lead to personal injury and/or damage to the unit or other equipment.
	This icon, followed by the word <b>NOTE</b> , is meant to highlight the parts of the text where important notes needful for a correct and reliable use of the device can be found. User must pay attention to them! Failure to comply with instructions could cause the equipment to be set wrongly: hence a faulty and improper working of the device could be the consequence.
	This icon is meant to highlight the parts of the text where suggestions useful for making it easier to set the device and optimize performance and reliability can be found. Sometimes this symbol is followed by the word <b>EXAMPLE</b> when instructions for setting parameters are accompanied by examples to clarify the explanation.

# Preliminary information

This guide is designed to provide the most complete and exhaustive information the operator needs to correctly and safely install and operate the **SMRA series bearingless absolute encoder**. SMRA is designed to measure rotary and linear displacements in industrial machines and automation systems. The measurement system includes a magnetic ring and a magnetic sensor with conversion electronics. The ring is magnetized with a coded sequence of North-South poles generating an absolute pattern. As the ring turns without contact, the sensor detects the rotation and yields the absolute position information through the SSI interface (order code SMRA-BG-... and SMRA-GG-...) or the BiSS C-mode interface (order code SMRA-I7-...).

It is mandatory to pair the sensor with the **MRA type magnetic ring**.

To make it easier to read and understand the text, this guide can be divided into three main sections.

In the first section some general information concerning the safety, the mechanical installation and the electrical connection as well as tips for setting up and running properly and efficiently the unit are provided.

In the second section, entitled **SSI interface**, both general and specific information is given on the SSI interface.

In the third section, entitled **BiSS C-mode interface**, both general and specific information is given on the BiSS C-mode interface. In this section the parameters implemented in the unit are fully described.

## 1 – Safety summary

### Safety

- Always adhere to the professional safety and accident prevention regulations applicable to your country during device installation and operation;
- installation and maintenance operations have to be carried out by qualified personnel only, with power supply disconnected and stationary mechanical parts;
- device must be used only for the purpose appropriate to its design: use for purposes other than those for which it has been designed could result in serious personal and/or the environment damage;
- high current, voltage and moving mechanical parts can cause serious or fatal injury;
- warning ! Do not use in explosive or flammable areas;
- failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture, and intended use of the equipment;
- Lika Electronic assumes no liability for the customer's failure to comply with these requirements.

### Electrical safety

- Turn OFF power supply before connecting the device;
- connect the unit according to the explanation in the section "4 – Electrical connections";
- connect Zero Setting/Preset and Counting direction inputs to 0VDC, if not used;
  - to set the encoder to zero/preset, connect Zero setting/Preset input to +VDC for 100  $\mu$ s at least, then disconnect +VDC; normally voltage must be at 0VDC; zero/preset setting must be performed after Counting direction setting; we suggest performing the zero/preset setting when the encoder is in stop;
  - Counting direction: increasing count = connect to 0VDC; decreasing count = connect to +VDC;
- in compliance with 2004/108/EC norm on electromagnetic compatibility, following precautions must be taken:
  - before handling and installing the equipment, discharge electrical charge from your body and tools which may come in touch with the device;
  - power supply must be stabilized without noise; install EMC filters on device power supply if needed;
  - always use shielded cables (twisted pair cables whenever possible);
  - avoid cables runs longer than necessary;
  - avoid running the signal cable near high voltage power cables;
  - mount the device as far as possible from any capacitive or inductive noise source; shield the device from noise source if needed;
  - to guarantee a correct working of the device, avoid using strong magnets on or near by the unit;





- minimize noise by connecting the shield and/or the connector housing and/or the sensor to ground. Make sure that ground is not affected by noise. The connection point to ground can be situated both on the device side and on user's side. The best solution to minimize the interference must be carried out by the user;
- do not stretch the cable; do not pull or carry by cable; do not use the cable as a handle.

### **Mechanical safety**

- Install the device following strictly the information in the section "3 - Mounting instructions";
- mechanical installation has to be carried out with stationary mechanical parts;
- do not disassemble the unit;
- do not tool the unit;
- delicate electronic equipment: handle with care; do not subject the device to knocks or shocks;
- protect the unit against acid solutions or chemicals that may damage it;
- respect the environmental characteristics of the product;
- we suggest installing the unit providing protection means against waste, especially swarf as turnings, chips, or filings; should this not be possible, please make sure that adequate cleaning measures (as for instance brushes, scrapers, jets of compressed air, etc.) are in place in order to prevent the sensor and the magnetic ring from jamming.

## 2 - Identification

Device can be identified through the **order code** and the **serial number** printed on the label applied to its body. Information is listed in the delivery document too. Please always quote the order code and the serial number when reaching Lika Electronic for purchasing spare parts or needing assistance. For any information on the technical characteristics of the product refer to the technical datasheet.



**Warning:** devices having order code ending with "/Sxxx" may have mechanical and electrical characteristics different from standard and be supplied with additional documentation for special connections (Technical Info).

### 3 – Mounting instructions



#### WARNING

Installation has to be carried out by qualified personnel only, with power supply disconnected and mechanical parts compulsorily in stop.



#### WARNING

Install the unit providing protection means against waste, especially swarf as turnings, chips or filings; should this not be possible, please make sure that adequate cleaning measures (as for instance brushes, scrapers, jets of compressed air, etc.) are in place in order to prevent the sensor and the magnetic ring from jamming.

Make sure the mechanical installation meets the system's requirements for both the sensor and the ring indicated in this guide.

### 3.1 Overall dimensions




Figure 1

### 3.2 Magnetic ring

It is mandatory to pair the sensor with the **MRA type magnetic ring**.

The Figure 1 shows how the sensor and the magnetic ring must be installed; the arrow indicates the **standard counting direction** (increasing count when the ring turns in the direction indicated by the arrow). See also the section "4.6 Counting direction input" on page 16.



#### WARNING

The system cannot operate if mounted otherwise than illustrated in Figure 1. Please mind the direction of the cable outlet.

### 3.3 Installing the system




Figure 2

#### 3.3.1 Mounting the magnetic ring

1. Mount the magnetic ring **2** on the motor shaft;
2. mount the locking ring **3** and fasten the whole assembly to the motor shaft by using six bolts type M3 x 20 UNI7688. Tighten the bolts following the sequence indicated in the Figure. Recommended tightening torque: **1.1 Nm**.

#### 3.3.2 Mounting the sensor

1. Fix the sensor **1** using two cylinder head bolts M4 x 25 UNI5931. Recommended tightening torque: **2.5 Nm**. Recommended **minimum bend radius** of the cable:  **$R \geq 42 \text{ mm}$** .

The max. allowed gap between the sensor and the magnetic ring is  $1 \pm 0.2 \text{ mm}$  ( $0.04'' \pm 0.008''$ ).



#### WARNING

Please be sure that the mounting tolerances indicated in Figure 3 are always met. Avoid contact between the parts.




Figure 3



### WARNING

Mount the sensor as shown in the Figures. Please mind the direction of the cable outlet. The system cannot operate if mounted otherwise than illustrated in the Figures.



### WARNING

The arrow in Figure 1 is intended to indicate the **standard counting direction** (count up information when the ring turns in the direction of the arrow). See also the section "4.6 Counting direction input" on page 16.





### WARNING

After having installed the sensor on the magnetic ring a zero/preset setting operation is compulsorily required. The zero/preset setting operation is further required every time either the sensor or the ring are replaced. For any information on the zero/preset setting operation please refer to the section "4.5 Zero setting/Preset input" on page 16 and (BiSS interface only) to the **Preset** registers on page 27.

### 3.3.3 Optional mounting tool

To ease the installation of the sensor we suggest using the optional mounting tool. The order code is: **TOOL LKM-2386** (for rings Ø 130 mm).



### 4 – Electrical connections



#### WARNING

Electrical connection has to be carried out by qualified personnel only, with power supply disconnected and mechanical parts compulsorily in stop.



#### WARNING

If wires of unused signals come in contact, irreparable damage could be caused to the device. Please insulate them singularly.

Function	M8 cable	M12 8-pin
<b>OVDC power supply</b>	Black	1
<b>+VDC power supply *</b>	Red	2
<b>Clock IN + / MA +</b>	Yellow	3
<b>Clock IN - / MA -</b>	Blue	4
<b>Data OUT + / SLO +</b>	Green	5
<b>Data OUT - / SLO -</b>	Orange	6
<b>Zero setting/Preset</b>	White	7
<b>Counting direction</b>	Grey	8

\* See the order code for power supply voltage level



#### EXAMPLE

SMRA-GG-1-08 +VDC = +5VDC  $\pm$  5%

SMRA-GG-2-08 +VDC = +10VDC +30VDC

#### 4.1 M8 cable specifications

Model : LIKA HI-FLEX M8 cable

Wires : 6 x 0.14 mm<sup>2</sup> + 2 x 0.22 mm<sup>2</sup> (26/24 AWG)

Shield : tinned copper braid

External diameter : Ø 5.3 mm ÷ 5.6 mm


Conductor resistance : < 148  $\Omega$ /km (0.14 mm<sup>2</sup>), < 90  $\Omega$ /km (0.22 mm<sup>2</sup>)

Minimum bend radius : Ø x 7.5

#### 4.2 M12 8-pin connector

Male, frontal side

A coding



### 4.3 Connection of the shield

For signals transmission always use shielded cables. The cable shielding must be connected properly to the metal ring nut of the connector in order to ensure a good earthing through the frame of the device.

### 4.4 Ground connection

Minimize noise by connecting the shield and/or the connector housing and/or the sensor to ground. Make sure that ground is not affected by noise. The connection point to ground can be situated both on the device side and on user's side. The best solution to minimize the interference must be carried out by the user.

### 4.5 Zero setting/Preset input

The output position information at a point in the shaft rotation can be set either to 0 (SSI interface) or to a desired value called preset (BiSS C interface; the preset value has to be set next to the registers **Preset**, see on page 27). The Zero setting/Preset input allows the operator to activate the zero/preset value through an input signal sent by a PLC or other controller. This can be very useful for setting the zero position of both the sensor and the machine. To activate the zero setting/preset function, connect the Zero setting/Preset input to +VDC for 100 µs at least, then disconnect +VDC; normally voltage must be at 0VDC; Zero setting/Preset must be set after Counting direction. We suggest setting the zero/preset when the encoder is in stop. If not used, connect the Zero setting/Preset input to 0VDC.



#### NOTE

In the BiSS interface the preset can be activated also by using the **Save parameters and activate Preset** function of the **Command** register. For detailed information please refer to the **Preset** registers on page 27 and the **Command** register on page 30.

### 4.6 Counting direction input

It is also referred to as Complementary input.

The **standard counting direction** is to be intended with ring turning as indicated by the arrow in Figure 1. The counting direction circuit allows to reverse the counting direction. In other words it allows the count up when the ring turns in reverse of the standard direction, i.e. in the opposite direction to the one shown by the arrow in Figure 1. Connect the Counting direction input to 0VDC if not used. Connect the counting direction input to 0VDC to have an increasing count when the ring turns as indicated by the arrow in Figure 1; connect the counting direction input to +VDC to have an increasing count



when the ring turns in reverse of the standard direction, i.e. in the opposite direction to the one shown by the arrow in Figure 1.

**WARNING**

After having set the new counting direction it is necessary to set the sensor to zero/preset.

### 5 – SSI interface

Order codes: SMRA-BG-...

SMRA-GG-...

#### 5.1 SSI (Synchronous Serial Interface)




SSI (the acronym for **Synchronous Serial Interface**) is a synchronous point-to-point serial interface engineered for unidirectional data transmission between one Master and one Slave. Developed in the first eighties, it is based on the RS-422 serial standard. Its most peculiar feature is that data transmission is achieved by synchronizing both the Master and the Slave devices to a common clock signal generated by the controller; in this way the output information is clocked out at each controller's request. Furthermore only two pairs of twisted wires are used for data and clock signals, thus a six-wire cable is required. The main advantages in comparison with parallel or asynchronous data transmissions are:

- less conductors are required for transmission;
- less electronic components;
- possibility of insulating the circuits galvanically by means of optocouplers;
- high data transmission frequency;
- hardware interface independent from the resolution of the absolute encoder.

Furthermore the differential transmission increases the noise immunity and decreases the noise emissions. It allows multiplexing from several encoders, thus process controls are more reliable with simplified line design and easier data management.

Data transmission is carried out as follows.

At the first falling edge of the clock signal (**1**, the logic level changes from high to low) the absolute position value is stored while at the following rising edge (**2**) the transmission of data information begins starting from the MSB.



At each change of the clock signal and at each subsequent rising edge (**2**) one bit is clocked out at a time, up to LSB, so completing the data word

transmission. The cycle ends at the last rising edge of the clock signal (3). This means that up to  $n + 1$  rising edges of the clock signals are required for each data word transmission (where  $n$  is the bit resolution); for instance, a 13-bit encoder needs 14 clock edges. If the number of clocks is greater than the number of bits of the data word, then the system will send a zero (low logic level signal) at each additional clock, zeros will either lead (LSB ALIGNED protocol) or follow (MSB ALIGNED protocol) or lead and/or follow (TREE FORMAT protocol) the data word. After the period  $T_m$  monoflop time, having a typical duration of 16  $\mu$ sec, calculated from the end of the clock signal transmission, the encoder is then ready for the next transmission and therefore the data signal is switched high.

The clock signal has a typical logic level of 5V, the same as the output signal which has customarily a logic level of 5V in compliance with RS-422 standard. The output code can be either Binary or Gray (see the order code).

### 5.2 MSB left aligned protocol

"MSB left aligned" protocol allows to left align the bits, beginning from MSB (most significant bit) to LSB (least significant bit); LSB is then sent at the last clock cycle. If the number of clock signals is higher than the data bits, then unused bits are forced to logic level low (0) and follow the data word. This protocol can be used in sensors having any resolution.

The word has a variable length according to resolution, as shown in the following table.

Sensor model	Ring model	Length of the word	Max. number of information
SMRA-BG-x-06-... SMRA-GG-x-06-...	MRA/130-64	13 bits	12 bits (4096 info/rev.)
SMRA-BG-x-07-... SMRA-GG-x-07-...	MRA/130-64	14 bits	13 bits (8192 info/rev.)
SMRA-BG-x-08-... SMRA-GG-x-08-...	MRA/130-64	15 bits	14 bits (16384 info/rev.)

The number of information per revolution results from:

$$2 \text{ to the power of resolution } * \text{ number of ring poles}$$



#### EXAMPLE

SMRA-GG-2-08-...: resolution = 08;  
MRA/130-64: number of poles = 64.

$$\text{Hence: } 2^8 * 64 = 256 * 64 = 16,384 \text{ information per revolution}$$

The output code of the sensor can be GRAY or BINARY (see the order code).

Structure of the transmitted position value:

SMRA-xx-x-06-...	bit	13	...	2	1
SMRA-xx-x-07-...	bit	14	...	2	1
SMRA-xx-x-08-...	bit	15	...	2	1
	value	MSB	...	LSB	Error bit


### 5.3 Recommended transmission rates

The SSI interface has a frequency of data transmission ranging between 100 kHz and 2 MHz.

The CLOCK signals and the DATA signals comply with the "EIA standard RS-422". The clock frequency (baud rate) depends on the length of the cable and must comply with the technical information reported in the following table:

Cable length	Baud rate
< 60 m	< 400 kHz
< 100 m	< 300 kHz
< 200 m	< 200 kHz
< 400 m	< 100 kHz

The time interval between two Clock sequence transmissions must be at least 16  $\mu$ s (  $T_p$  = pause time > 16  $\mu$ s).



### 5.4 Error bit

The error bit is intended to communicate the normal or fault status of the Slave.

"1": correct status (the sensor is working properly, there are no active errors)

"0": an error is active:

- position calculation error, invalid position value; the sensing electronics is not able to read the ring; this problem may be caused, for instance, by an excessive distance between the sensor and the ring, by a wrong/reversed assembly of the elements, by a damage to the magnetic surface of the ring; see the section "3.3.2 Mounting the sensor" on page 12;
- the power supply is not as required, please refer to the order code;
- EEPROM error.



### NOTE

For any information on the structure of the position information word, please refer to the section "5.2 MSB left aligned protocol" on page 19.


The operating or fault status of the device is shown visually also by the LED installed in the side of the sensor, refer to the section "7 - Diagnostic LED" on page 33.

For any information on errors and their solution please refer to the sections "8 - Error and fault diagnostics" on page 34 and "10 - Troubleshooting" on page 36.

### 5.5 Helpful information

- The position information increases when the ring rotates as indicated by the arrow in Figure 1.
- At installation always execute a zero setting operation of the position.

### 5.6 Recommended SSI circuit



### 6 – BiSS C-mode interface

Order code: SMRA-I7-...

Lika encoders are always Slave devices and comply with the "BiSS C-mode interface" and the "Standard encoder profile".

Refer to the official BiSS website for all information not listed in this manual ([www.biss-interface.com](http://www.biss-interface.com)).

The device is designed to work in a point-to-point configuration and has to be installed in a "single Master, single Slave" network.

CLOCK IN (MA) and DATA OUT (SLO) signal levels are according to the "EIA standard RS-422".




#### WARNING

Never install the encoder in a "single Master, multi Slave" network.

#### 6.1 Communication

The BiSS C-mode protocol uses two types of data transmission protocols:

- **Single Cycle Data (SCD):** it is the main data transmission protocol. It is used to send process data from the Slave to the Master. For any information refer to the section "6.2 Single Cycle Data SCD" on page 23.
- **Control Data (CD):** transmission of a single bit following the SCD data. It is used to read or write data into the registers of the Slave. For any information refer to the section "6.3 Control Data CD" on page 25.



### 6.2 Single Cycle Data SCD

SCD structure is different according to the resolution of the SMRA model encoder.

#### 6.2.1 SCD structure

SCD data has variable length according to the resolution of the encoder. It consists of the following elements: position value (**Position**), 1 error bit nE (**Error (nE)**), 1 warning bit nW (**Warning (nW)**) and a 6-bit CRC Cyclical Redundancy Checking (**CRC**).

12-bit encoder model (SMRA-xx-x-06)

bit	23 ... 8	7	6	5 ... 0
function	Position	Error (nE)	Warning (nW)	CRC

13-bit encoder model (SMRA-xx-x-07)

bit	24 ... 8	7	6	5 ... 0
function	Position	Error (nE)	Warning (nW)	CRC

14-bit encoder model (SMRA-xx-x-08)

bit	26 ... 8	7	6	5 ... 0
function	Position	Error (nE)	Warning (nW)	CRC

#### Position

It is the process data transmitted by the Slave to the Master. It has a variable length according to the resolution of the encoder.

The transmission starts with MSB (most significant bit) and ends with LSB (less significant bit).



#### NOTE

The number of information per revolution results from:

$$2 \text{ to the power of resolution} * \text{number of ring poles}$$



#### EXAMPLE

SMRA-I7-2-08-...: resolution = 08;

MRA/130-64: number of poles = 64.

$$\text{Hence: } 2^8 * 64 = 256 * 64 = 16,384 \text{ information per revolution}$$

### Error (nE)

(1 bit)

The error bit nE is intended to communicate the normal or fault status of the Slave.

"1": correct status (the sensor is working properly, there are no active errors)

"0": an error is active:

- position calculation error, invalid position value; the sensing electronics is not able to read the ring; this problem may be caused, for instance, by an excessive distance between the sensor and the ring, by a wrong/reversed assembly of the elements, by a damage to the magnetic surface of the ring; see the section "3.3.2 Mounting the sensor" on page 12;
- the power supply is not as required, please refer to the order code;
- EEPROM error.



### NOTE

The operating or fault status of the device is shown visually also by the LED installed in the side of the sensor, refer to the section "7 - Diagnostic LED" on page 33.

For any information on errors and their solution please refer to the sections "8 - Error and fault diagnostics" on page 34 and "10 - Troubleshooting" on page 36.

### Warning (nW)

(1 bit)

The warning bit nW is intended to communicate the normal status of the Slave or the presence of a fault condition that does not prevent the unit from running.

"1": correct status (the sensor is working properly, there are no active warnings)

"0": a warning is active:

- distance error: the specified mounting tolerances between the sensor and the ring are not met, see the section "3.3.2 Mounting the sensor" on page 12;
- frequency error: the rotation speed of the ring is greater than the maximum allowed one. For example: for MRA/130-64 the maximum rotation speed is 7,000 rpm.

When a warning condition occurs, the position information is good, however the system precision may be worse than in a normal condition. For such reason it is necessary to comply with the mounting tolerances and/or to drop the rotation speed of the ring. The LED does not light up.





### NOTE


For any information on fault conditions and their solution please refer to the sections "8 – Error and fault diagnostics" on page 34 and "10 – Troubleshooting" on page 36.

### CRC

Correct transmission control (inverted output). Cyclical Redundancy Checking is an error checking which is the result of a "Redundancy Checking" calculation performed on the message contents. This is intended to check whether the transmission has been performed properly. It is 6-bit long.

Polynomial:  $X^6 + X^1 + 1$  (binary: 1000011)

### Logic circuit



### 6.3 Control Data CD

Main control data is described in this section. Please refer to the official BiSS documents for complete CD structure: "BiSS C Protocol Description" in the BiSS homepage (<http://www.biss-interface.com/>).

### Register address

It allows to enter the address of the register you need either to read or write. It is 7-bit long.

### RW

**RW** = "01": when you need to write in the register.

**RW** = "10": when you need to read from the register.

It is 2-bit long.

### DATA

When you need to write in a register (**RW** = "01"), it allows to set the value to be written in the register (transmitted by the Master to the Slave).

When you need to read from a register (**RW** = "10"), it shows the value read in the register (transmitted by the Slave to the Master).

It is 8-bit long.

### Data bit structure:


bit	7	...	...	0
	MSB	...	...	LSB

### CRC

Correct transmission control (inverted output). Cyclical Redundancy Checking is an error checking which is the result of a "Redundancy Checking" calculation performed on the message contents. This is intended to check whether the transmission has been performed properly. It is 4-bit long.

Polynomial:  $X^4 + X^1 + 1$  (binary: 10011)

### Logic circuit



### 6.4 Implemented registers

Register (hex)	Function
12 - 13	Preset
40	Preset setting enable
60 ... 63	Serial number
77	Command
78 ... 7B	Device ID
7C	Time-out
7D	Software version
7E - 7F	Manufacturer ID

All registers described in this section are listed as follows:

#### Function name

#### [Address, Attribute]

Description of the function and specification of the default value.

- Address: the register address is expressed in hexadecimal notation.
- Attribute:    ro = read only  
                  rw = read and write  
                  wo = write only
- Default parameter value is written in **bold**.

#### Preset

[12 - 13, rw]



#### WARNING

You are allowed to enter a value next to the **Preset** registers only after having set the value "01" next to the **Preset setting enable** register. As soon as you have entered the desired preset value, you must set the value "00" next to the **Preset setting enable** register and then save data.

These registers allow the operator to set the Preset value. Preset function is meant to assign a certain value to a desired physical position of the encoder. The chosen physical position (i.e. the transmitted position value) will get the value set next to these registers and all the previous and following positions will get a value according to it. For instance, this can be useful for getting the zero point of the encoder and the zero point of the application to match. The preset value will be set for the position of the encoder in the moment when the command is sent through the **Save parameters and activate Preset** function of the **Command** register (or through the Zero setting/Preset input signal, see on section "4.5 Zero setting/Preset input" page 16).

After having entered a value next to the **Preset** registers you can either save it without activating the preset function or both save and activate it at the same time. Use the **Save parameters** function (set "01" in the **Command** register) to save the new Preset value without activating it.

Use the **Save parameters and activate Preset** function (set "02" in the **Command** register) to both save and activate the new Preset value.

The max. allowed Preset value depends on the resolution of the device:

resolution = 12 bits → max preset = 0F FFh

resolution = 13 bits → max preset = 1F FFh

resolution = 14 bits → max preset = 3F FFh

Default = 00 00h.

Min. Value = 00 00h

Max. value = according to resolution



### NOTE

We suggest setting the preset when the ring is not rotating.

**Preset register structure:**

Register	12	13
	LSB	MSB
	$2^7 - 2^0$	$2^{15} - 2^8$



### NOTE

The Preset value must be expressed in a 16-bit format, thus the Preset value you want to set must be adjusted by multiplying it by the factor  $2^{16-nbit}$ , where nbit is the number of bits relating to the resolution of the encoder. See the following example.



### PRESET SETTING EXAMPLE

In a 14-bit resolution encoder ( $2^{14} = 16,384$  information), you want to set the following **Preset** value =  $10,000_{10}$ .

1. As previously stated, first of all you must enable the setting of the **Preset** registers by entering the value "01" next to the **Preset setting enable** register.
2. Then multiply the desired preset value ( $10,000_{10}$ ) by the factor  $2^{16-nbit}$ , i.e.  $2^2$  ( $16 - 14 = 2$ ).  
Thus the **Preset** value to be set in the registers will be:  
 $10,000_{10} * 2^{16-14} = 40,000_{10} = 9C\ 40$  hex.
3. Then, before saving the entered data, set the value "00" next to the **Preset setting enable** register.

4. To save the new Preset value, you must use the **Save parameters** function in the **Command** register (set "01" in the **Command** register).
5. Otherwise, to both save and activate the the new Preset value at the same time, you must use the **Save parameters and activate Preset** function in the **Command** register (set "02" in the **Command** register).

Function	ADDR	DATA Tx
Preset setting enable	40	01

Writing in the Preset register	12	40
	13	9C

Preset setting enable	40	00
-----------------------	----	----

Save parameters function in the Command register	77	01
--	----	----

or

Save parameters and activate Preset function in the Command register	77	02
---	----	----

### Preset setting enable

[40, wo]

It allows the operator to enable the setting of the **Preset** registers. You are allowed to set a new preset value only after having entered the value "01" next to this **Preset setting enable** register. As soon as you have entered the desired preset value, you must set the value "00" next to this **Preset setting enable** register and then save data.

### Serial number

[60 ... 63, ro]

These registers contain the serial number of the device expressed in hexadecimal notation.

Register 60: year of production.

Register 61: week of production.

Registers 62 and 63: serial number in ascending order.

### Command

[77, wo]

Value	Function
01	Save parameters
02	Save parameters and activate Preset

After having set a new value in any register use the **Save parameters** function in the **Command** register to save the new value. Set "01" in the **Command** register.

After having set a new value in any register use the **Save parameters and activate Preset** function in the **Command** register to both save the new value and activate the preset function at the same time. Set "02" in the **Command** register.

After having sent the command the register is set back to "00" automatically. Wait 30 ms at least (EPROM writing time) before activating a new function.

### Device ID

[78 ... 7B, ro]

These registers contain the Device ID. Identification name is expressed in hexadecimal ASCII code.

Register	78	79	7A	7B
Hex	53	4D	52	41
ASCII	S	M	R	A

### Time-out

[7C, rw]

It allows to set the minimum interval time between two transmission sequences. After having set the desired time-out value, save data using the **Save parameters** function (**Command** register = "01").

Time-out	Bit 7 ... bit 2	Bit 1	Bit 0
16 $\mu$ s	0 ... 0	0	0
8 $\mu$ s	0 ... 0	0	1
<b>2 <math>\mu</math>s (default)</b>	0 ... 0	1	0
1 $\mu$ s	0 ... 0	1	1



#### NOTE

You can save the entered time-out value also by using the **Save parameters and activate Preset** function in the **Command** register (**Command** register = "02"). Please note that in this case you both save time-out data and activate the preset function (see on page 27).

### Software version

[7D, ro]

This register contains the software version of the device. Data is expressed in hexadecimal ASCII code.

Register	7D
Hex	xx
ASCII	x



### EXAMPLE

If the value in the register 7D is "31" hex, then the software version is "1".

### Manufacturer ID

[7E – 7F, ro]

These registers contain the Manufacturer ID. Identification name is expressed in hexadecimal ASCII code.

Register	7E	7F
Hex	4C	69
ASCII	L	i


Li = Lika Electronic

## 6.5 Application notes

Data transmission:

Parameter	Value
Clock Frequency	min 200KHz, max 10MHz
BiSS time-out	It can be set up, see the <b>Time-out</b> register

## 6.6 Recommended BiSS input circuit





## 7 – Diagnostic LED

One LED is installed in the side of the sensor and is designed to show visually the operating or fault status of the device, as explained in the following table. The operating or fault status of the device is also communicated through the error bit, refer to the section "5.4 Error bit" on page 20 (SSI interface) or to the section "Error (nE)" on page 24 (BiSS interface).

LED	Description
OFF	The sensor is working properly, there are no active errors.
ON <i>lit red</i>	Position calculation error, invalid position value; the sensing electronics is not able to read the ring; this problem may be caused, for instance, by an excessive distance between the sensor and the ring, by a wrong/reversed assembly of the elements, by a damage to the magnetic surface of the ring; see the section "3.3.2 Mounting the sensor" on page 12.
	The power supply is not as required, please refer to the order code.
	EEPROM error.

For further information refer also to the sections "8 – Error and fault diagnostics" on page 34 and "10 – Troubleshooting" on page 36.

## 8 – Error and fault diagnostics

At power on or during operation the following errors may occur:

- when switching on the system an alarm is triggered through both the diagnostic LED and the dedicated bit (SSI interface: refer to the section "5.4 Error bit" on page 20; BiSS interface: refer to the section "Error (nE)" on page 24): the ring is not read correctly; it may be due to one of the following reasons: the ring and/or the sensor are not mounted properly (see the section "3 – Mounting instructions" on page 11); the ring magnetic surface is damaged somewhere; the sensor is not working properly; this may cause invalid data to be transmitted; as soon as the problem is solved the LED switches off and the error bit switches to high logic level;
- during operation an alarm is triggered through both the diagnostic LED and the dedicated bit (SSI interface: refer to the section "5.4 Error bit" on page 20; BiSS interface: refer to the section "Error (nE)" on page 24): as previously stated, the ring is not read correctly; it may be due to one of the following reasons: the ring and/or the sensor are not mounted properly (see the section "3 – Mounting instructions" on page 11); the ring magnetic surface is damaged somewhere; the sensor is not working properly; furthermore, the alarm may be caused by a position calculation error so that the resulting position value is invalid. The last valid position is "frozen" (kept in memory) until the next valid position is detected on the ring.



### NOTE

In the SSI interface, the device status is both shown visually through the diagnostic LED (see the section "7 – Diagnostic LED" on page 33) and transmitted via the error bit (see the section "5.4 Error bit" on page 20).

In the BiSS interface, the device status is both shown visually through the diagnostic LED (see the section "7 – Diagnostic LED" on page 33) and transmitted via the error bit (see the section "Error (nE)" on page 24). Refer also to the section "Warning (nW)" on page 24.

For any further information refer also to the section "10 – Troubleshooting" on page 36.

## 9 – Maintenance



### WARNING

Maintenance operations have to be carried out by qualified personnel only, with power supply disconnected and mechanical parts compulsorily in stop.

The magnetic measurement system does not need any special maintenance; anyway it has to be handled with the utmost care as any delicate electronic equipment. From time to time we recommend the following operations:

- periodically check the soundness of the structure and make sure that there are no loose screws; tighten them if necessary;
- check the gap between the sensor and the magnetic ring. Wear of the machine may increase the tolerances;
- the surface of the magnetic ring has to be regularly cleaned using a soft and clean cloth to remove dust, chips, moisture etc.

## 10 – Troubleshooting

The following list shows some typical faults that may occur during installation and operation of the magnetic measurement system.

### **Fault:**

The system does not work (no pulse output).

### **Possible cause:**

- The ring and/or the sensor are not installed properly. The ring and the sensor need to be coupled as explained in the mounting instructions. The system cannot operate if mounted otherwise. For correct installation please refer to the section "3 – Mounting instructions" on page 11.
- Installation does not meet the mounting tolerances between the sensor and the ring indicated in this guide; the sensor hits the surface of the ring or is too close to/far from it. Check whether the sensor sensitive part is damaged.
- A magnetic part has been placed between the sensor and the magnetic surface of the ring.
- The sensor has been damaged by short circuit or wrong connection (reverse polarity protection is provided for the version SMRA-xx-2-... only).

### **Fault:**

The measured values are either inaccurate or not provided in the whole circumference of the ring.

### **Possible cause:**

- The sensor is not installed properly on the ring. See the section "3 – Mounting instructions" on page 11.
- The connection cable runs near high voltage cables or the shield is not connected properly. Check the earthing point.
- The frequency of Master clock is set too high or too low and the transmission cannot be synchronized correctly. See the section "5 – SSI interface" on page 18.
- A section of the magnetic surface has been damaged mechanically or magnetically; this may cause a failure to read the position or a position calculation error so that the resulting position value is invalid.
- The measuring error is caused by a torsion or plays in the machine structure. Check for movements in the mechanics of the machine.

## 11 - Default parameters list

BiSS C-mode interface

Parameters list	Default value *		
Preset	00 00		
Preset setting enable	00		
Time-out	02		

\* All values are expressed in hexadecimal notation.

This page intentionally left blank


This page intentionally left blank



Edit	Document release	Description
0	1.0	1 <sup>st</sup> issue
1	1.1	SSI bit error added, section "6 - BiSS C-mode interface" added, section "8 - Error and fault diagnostics" added, general review
2	1.2	Error bit and LED operation meaning update, new optional mounting tool



Dispose separately



**Lika Electronic**

Via S. Lorenzo, 25 - 36010 Carrè (VI) - Italy

Tel. +39 0445 806600

Fax +39 0445 806699

Italy : eMail [info@lika.it](mailto:info@lika.it) - [www.lika.it](http://www.lika.it)

World : eMail [info@lika.biz](mailto:info@lika.biz) - [www.lika.biz](http://www.lika.biz)